


PROXIMITY SWITCH SSW-CP Cylindrical Proximity Switch

Function: The Cylindrical proximity switch provides a switch closure when any part of the body comes within range of its target area. The range of the Cylindrical Proximity is from 3/8" to touch, depending on how the sensitivity is set. Switch closure is maintained for as long as the body part is within that sensing range.

Usage: People with limited range of movement and limited strength can use this switch to activate any adapted appliance. The types of appliances that can be activated include personal computers, communication systems, environmental controls, and toys.



Set-Up:

1. It is recommended that the Proximity Control Module be fully charged before using. The Proximity Control Module should be charged for at least 3 to 4 hours before using it. The Proximity Control Module is charging when the LED is RED and fully charged when the LED turns GREEN. The Proximity Control Module can be used while the unit is charging.
2. Connect one end of the 3.5mm cable into the appliance the user intends to operate.
3. Connect opposite end of the 3.5mm cable into the jack on the Proximity Control Module labeled OUTPUT JACK.
4. Set the power switch (see diagram above) to the desired mode: ON w/Tone (a beep sound will be heard each time the sensor is activated) or ON no Tone (no tone will be heard when the sensor is activated).
5. Place the sensor in an area close to the user's best controlled movement.
6. Set the sensing range by turning the adjustment wheel (see diagram above – BOTTOM VIEW OF SENSOR) with the small slotted screwdriver provided. Turning the adjustment wheel clockwise will increase the sensing range and turning the adjustment wheel counter-clockwise will reduce the sensing range. The minimum sensing range is where you will need to touch the tip of the sensor.
7. Activation can be achieved when the user's body part enters the sensing range (3/8 inch to touch).
8. Turn the Proximity Control Module OFF when not in use.

Battery:

The Proximity Control Module has an internal 12Volt rechargeable battery. The battery should stay charged for about a week with normal usage, recharge as needed.